

## ACUSAT AQ SAFE WIPES

Acusat AQ Safe wipe is an impregnated wipe specially developed by Gekatex from a nonwoven, Sorball, and a solvent based on quaternary ammonium Approved according to standard EN 14476 for uses TP2 and TP4. The pre-saturated wipe avoids any danger of liquid projection, overconsumption of chemicals and therefore the storage of dangerous products in your premises.

### Product description

#### Characteristics:

- Solvent based on quaternary ammonium approved according to standard EN 14476 for TP2 and TP4 uses and Polypropylene non-woven wipe.
- Non-hazardous product usable without PPE in any environment
- Compatible with food contact
- Optimal exposure and drying time for a perfect virucidal action.

PROPERTIES	STANDARD	MICROORGANISMS	CONTACT TIME (In minutes)
BACTERICIDAL	EN1276	Pseudomonas Anginosa	1 et 5
		Enterrococcus hirae	1 et 5
		Staphylococcus aureus	1 et 5
		Escherichia Coli	1 et 5
	EN16615	Pseudomonas Anginosa	1
		Enterrococcus hirae	1
		Staphylococcus aureus	1
	EN13727	Pseudomonas Anginosa	1
		Enterrococcus hirae	1
Staphylococcus aureus		1	
YEASTICIDAL	EN1650	Candida Albicans	1
	EN16615	Candida Albicans	1
	EN13624	Candida Albicans	1
FUNGICIDAL	EN13697	Candida Albicans	15
		Aspergillus brasiliensis	15
	EN1650	Candida Albicans	15
		Aspergillus brasiliensis	15
VIRUCIDAL	EN14476	Vaccina virus Ankara	1
		Virus enveloppés (Coronavirus, influenza, Herpes,...)	1

#### Recommended applications:

- Disinfection for all surfaces, very efficient, quick and without rinsing.
- Ideal for common areas, toilets, kitchens, offices, elevators, vehicle interiors, rental equipment, etc.
- TP2 - Disinfectant used in the private sector and in the field of public health.
- TP4 - Disinfectant for surfaces in contact with food and feed.





Precautions for use Material Safety data sheet on request

P102 Keep out of reach for children

P502 - Refer to manufacturer/supplier for information on recovery/recycling.

Make a preliminary test on an inconspicuous part of the surface to be treated. Rub the surfaces to be cleaned and disinfected with the wipe. Do not rinse, let dry.

Use biocides safely. Before use, read the label and product information.

### Product options and packaging



Stand up for pre-saturated wipes

Code	Wipe	Dimensions	Wipes/Bag	Bags/Box
WS00003609	Sorball	32x20 cm	40	12

### Storage:

- Between 5°C and 35°C
- 1 year

### Why using pre-saturated wipes is better than a dry wipe with a bottled liquid?

- No dangerous Chemical drums on your site
- Reduce wipes waste and chemical Consumption by 50%
- Simplified Chemical Transport and Storage
- Time Saving process due to the easier product use
- VOC reduction to achieve European legislation
- Limits risk of dangerous chemical product spillage

